

How to connect a Huawei switch to a DHCP server



AI Overview

A Huawei switch can obtain IP addresses from a DHCP server by configuring its interfaces as DHCP clients or by setting up the switch itself as a DHCP server using a global or interface-based address pool. Configuring the Switch as a DHCP Client

Access the switch CLI and enter system view:
`CodeCopy system-view` Select the interface that will connect to the DHCP server:
`CodeCopy interface GigabitEthernet 0/0/1` Enable DHCP client mode on the interface:
`CodeCopy ip address dhcp-alloc` Verify the IP assignment:
`CodeCopy display ip interface brief` This allows the switch to automatically obtain an IP address from a DHCP server on the same network segment.

Configuring the Switch as a DHCP Server

Huawei switches can also act as DHCP servers if no external DHCP server is available:

Enter system view:
`CodeCopy system-view` Create a global DHCP address pool:
`CodeCopy dhcp enable`
`ip pool POOL_NAME network 192.168.1.0 24 gateway-list 192.168.1.1 excluded-ip-address 192.168.1.1 192.168.1.10` Bind the pool to an interface (if using interface-based DHCP):
`CodeCopy interface GigabitEthernet 0/0/1 dhcp select global` Verify DHCP server status:
`CodeCopy display dhcp server ip-in-use` This configuration allows connected clients to automatically receive IP addresses from the switch.

Using DHCP Relay

If the DHCP server is on a different subnet: Enable DHCP relay on the switch interface:
`CodeCopy interface Vlanif 10 dhcp select relay`
`dhcp relay server-ip 192.168.2.100` Ensure the switch can route packets between the client and the DHCP server.

Key Considerations

Ensure the IP address pool does not overlap with static IPs or other DHCP servers. Only certain Huawei models support Layer 3 interfaces for DHCP server functionality; Layer 2 interfaces require relay to a DHCP server. Use a trusted DHCP server to prevent spoofing and network conflicts. By following these...

Article Content

Typical DHCP Configuration

Use a Huawei S series switch as an example for the DHCP server (Switch_1). Configure the interface link types and VLANs on LSW_1 and LSW_2 to implement Layer 2 communication.

Huawei Switch How To

HUAWEI SWITCH S5700 - HOW TO Configuring a basic DHCP server With this simple procedure we will show how to configure a global address pool to allocate IP addresses for clients when the clients

How To Configure the S6700 Series Switch A Dhcp Server

The configuration roadmap is as follows: Configure the DHCP server function on the Switch to dynamically assign IP addresses to the terminals on the two network segments.

Ruijie RG-S3760 switch configuration Telnet, SSH,

Today I bring you how to configure Telnet and SSH configuration on Huawei switches. The experimental topology is as follows Experimental topology

Huawei DHCP server configuration

This article describes two ways in which a DHCP server can be configured on a Huawei router or switch

Example for Configuring a DHCP Relay Agent

This guide provides an example configuration for a DHCP relay agent, enabling communication between DHCP clients and servers across different network segments.

Huawei: How to configure IP-Helper/DHCP relay

This article describes how to configure IP-Helper/DHCP relays on a Huawei switch or router

Configuring a DHCP Server

Before enabling the DHCP server function, enable DHCP in the system view. The dhcp enable command is the prerequisite for configuring DHCP-related functions, including DHCP relay, DHCP

What Is the Default Username and Password for Cisco

Learn the default Cisco switch username and password. Discover which models use "cisco/cisco," why most have no defaults, and how to secure login access

Example for Configuring a DHCP Server and a DHCP Relay Agent

Example for Configuring a DHCP Server and a DHCP Relay Agent Networking Requirements When the DHCP server and clients are on different network segments, a DHCP relay

Sx300 Series Switches Typical Configuration Examples (V200)

Use a Huawei S series switch as an example for the DHCP server (SwitchB). On the LSW, configure the interface link type and VLAN to implement Layer 2 communication.

Example for Configuring a DHCP Client

Networking Requirements In Figure 4-17, Switch_1 functions as a DHCP client and needs to dynamically obtain an IP address, DNS server address, and gateway address from a DHCP server

The Network DNA: Networking, Cloud, and Security

Master networking, cloud, and security with in-depth analysis, tutorials, and research. Stay ahead of the curve with our expert tech blog.

PPPoE vs DHCP in FTTH Networks: Internet Access Methods

Post 20 PPPoE vs DHCP in FTTH Networks | How Customers Get Internet Access Introduction When an ONT is successfully connected to an OLT, the customer is not automatically connected to the

How DHCP and DNS Work: A Visual Guide

📺 DHCP & DNS Explained with Visuals! If you're diving into networking or just need a quick brush-up, here's a simple breakdown of two core protocols: 📺 DHCP (Dynamic Host Configuration ...

HUAWEI S Series Switch-Configure a DHCP Server and a DHCP

HUAWEI S Series Switch-Configure a DHCP Server and a DHCP Relay Agent Huawei Documentation Insights 32.3K subscribers 55 12K views 8 years ago

DHCP Configuration on Huawei Switch - SYSTEMCONF

Huawei Switch Static IP If you want to assign a static IP for your servers or special devices (fax, printer, etc.), you can do this with the command

How to Configure Huawei Switch VLANs, SVI, DHCP & Relay Agent

📺 Learn How to Configure DHCP & Relay Agent on Huawei Switch! 📺 Are you struggling to set up DHCP and Relay Agent on your Huawei switch? In this tutorial, I'll walk you through a step-by ...

Configuring a DHCP Server

This guide provides step-by-step instructions for configuring a DHCP server on Huawei devices to efficiently manage IP address allocation.

How to Configure Huawei Switch VLANs, SVI, DHCP & Relay Agent

In this tutorial, I'll walk you through a step-by-step configuration to ensure smooth IP address assignment across different VLANs.

01-03 DHCP CONFIGURATION

In addition, wireless networks and mobile devices mean that IPv4 addresses and client locations are liable to change. DHCP is introduced to automate the assignment of network parameters, including

How to configure a Huawei Device as DHCP Server

In this video, you will learn how to configure a Huawei device (router, switch, WLAN controller, etc.) as DHCP server with two different options.

Configuring a DHCP Server

The dhcp enable command is the prerequisite for configuring DHCP-related functions, including DHCP relay, DHCP snooping, and DHCP server. These functions take effect only after the

Configuring DHCP

For more information about DHCP configuration, see DHCP Configuration in the S1720, S2700, S5700, and S6720 V200R011C10 Configuration Guide - IP Service. In the following operations, the DHCP

Huawei Switch How To

The document describes how to configure a DHCP server on a Huawei S5700 switch to assign IP addresses to clients from two address pools. It involves

Example for Configuring the Device as a DHCP Server (Based on the ...

Example for Configuring the Device as a DHCP Server (Based on the Interface Address Pool) Networking Requirements As shown in Figure 3-12, an enterprise plans two network segments

01-03 DHCP CONFIGURATION

When a switch functions as a DHCP client and multiple DHCP servers exist on the network, the DHCP client polls DHCP servers according to the sequence of receiving DHCP Offer messages.

Huawei DHCP server configuration

If no separate DHCP server is available the Huawei router/switch can also be configured as a DHCP server. There are two ways in which this can be done which are described here. Central

Contact Us

For more information, pricing, or custom solutions, please contact us:

Website: <https://www.sabineamsee.co.za>

Email: info@sabineamsee.co.za

Phone: +27 82 415 6793

Address: Unit 7, Innovation Park, 34 Electron Road, Kempton Park, 1620, South Africa

This document is for informational purposes only. Specifications subject to change without notice.

